

### 5.3. Sewing Wick

The roving is made from the inside of the cushion and pillow sides and is used to ensure that the upholstery is seen properly. Long strip sold. Available in various thicknesses depending on the place of use.

1 to 8 thin-thickness wicks are used for seat edges.

8-12 thick rovings are used in the outer rear. The reason is to hide the gun nails or clips.



Picture 5.5. Wick



Picture 5.6. Edge wicked cushion