

2.1. Introducing

They are natural or artificial plates that used on wooden or steel constructions which is prepared for sitting furnitures.

This kind of battenboards has hard upholstering generally. Rubber or foam with fabric get cut on plates and stapled under the plate.



Picture 2.1: Dolu telora tablası

Filled furniture blocks montage according to measure where they place and shape by cutting any blocks after the furniting part.



Resim 2.2: Filled furniture frame

Filled furniture frames have different types which is used without furniting. These are produced in a serial way.