

2.2. Techniques of Construction

2.2.1. Straight filled furniture frame

They are used in modern furniture. There is an incline in the part of sitting which is narrowed to the back side. It is easy for producing. According to the structure of using thickness can change.

Measurement of furniture frame is done in accordance to chair. The field of sitting of chair is narrowed to the back. Availability of this situation changes the process of measurement. According to measurement, circle and line is cut in saw machine.



Resim 2.3: Straight filled furniture frame