

4.1. Construction technics of unsprung upholstery on colon

- The hammering places and heights of colons which is used in upholstery is branded.
- If it is necessary, the quilted is hammered before colons on the furniture frame.
- The colons in the way of superposed of one point is attached stretchly and carefully on the furniture frames.



Picture 4.4: Hammering colons on the lining or without lining to stable furniture frame



Picture 4.5: Hammering colons

The upholstery surface is prepared by attaching one layer quilted on the colons.



Picture 4.6: Hammering of lining cloths

Lining cloth is firmly attached to back side after necessary adjustments by hammering with staple or nail .



Picture 4.7: Placing stuffing material

Stuffing material which is to be used is properly placed under the lining cloth and attached furniture frame tensely One layer fiber is also placed on it.



Picture 4.8: Placing fiber

Stuffing material çit necessary measurement is tensely ixed from few points on the fiber from begining from front part of fiber . Stuffing materyal is firmmed with staple and nail.



Picture 4.9: Hammering of stuffing material