
3.2.8 Adjusting the Thread Tension

The movement of the yarns is related to the thread tension setting. To increase yarn tension; adjusting nut in clockwise direction; turn the nut counterclockwise to decrease the tension



Picture 3.2.10 Tension Adjustment